



AllClear Landing Gear Repair Services

AllClear's Repair Services segment is an FAA (3KRR581C) approved repair station specializing in the complete repair, overhaul, and inspection of landing gear for C-130, F-16, KC-135, P-3, and 707 derivative platforms.



Boeing 707 (E-3, E-6, E-8)
Main Landing Gear



Boeing 707 (E-3, E-6, E-8)
Main Landing Gear



Lockheed L-100 (C-130)
Nose Landing Gear



Product Offering Highlights

- » Over two decades of landing gear support
- » On-site engineering support
- » OEM partnerships
- » Top notch customer service
- » Competitive price and delivery
- » Customer technical support
- » On-site machining capability
- » Upgraded facilities and equipment



Quality &
Compliance



AllClear
2525 Collier Canyon Rd.
Livermore, CA 94551

www.GoAllClear.com
sales@GoAllClear.com





Landing Gear Repair Services

P/N	DESCRIPTION	NSN
3001011-3	Strut Assy Nose Landing Gear	
3302196-13	Strut Assy Main Landing Gear Shock	
3302196-15	Strut Assy Main Landing Gear Shock	
3302196-19	Strut Assy Main Landing Gear Shock	1620-01-438-6191
3303591-1	Strut Assy Nose Landing Gear	1620-00-505-1184
3303591-3	Strut Assy Nose Landing Gear	1620-00-505-1184
3303595-1	Strut Assy Nose Landing Gear	1630-01-391-7191
3303595-5	Strut Assy Nose Landing Gear	1620-01-648-1905
3314203-3	Strut Assy Nose Landing Gear	1620-01-045-8540
3314205-3	Strut Assy Nose Landing Gear	
3316498-1	Strut Assy Main Landing Gear Shock	1620-01-170-8325
3316498-7	Strut Assy Main Landing Gear Shock	1620-00-896-1203
3316500-13	Strut Assy Nose Landing Gear	1620-01-304-4562
3316500-15	Strut Assy Main Landing Gear Shock	1620-01-304-7618
3401095-11	Strut Assy Nose Landing Gear	1620-00-996-8172
3635900-1A	Strut Assy Nose Landing Gear	
363590-5	Strut Assy Nose Landing Gear	
363590-7	Strut Assy Nose Landing Gear	1620-00-784-5563
364653-2A	Strut Assy Nose Landing Gear	1620-00-111-1417
370438-1	Strut Assy Main Landing Gear Shock	1620-00-623-8911
371671-1	Strut Assy Nose Landing Gear	1620-00-613-7201
388058-1	Strut Assy Main Landing Gear Shock	1620-00-896-1203
388058-19	Strut Assy Main Landing Gear Shock	1620-01-419-9739
388058-9	Strut Assy Main Landing Gear Shock	1620-00-306-4360
388067-7	Strut Assy Nose Landing Gear	
388067-9	Strut Assy Nose Landing Gear	
388071-1	Strut Assy Nose Landing Gear	1620-00-896-1209
388071-3	Strut Assy Nose Landing Gear	1620-00-085-2624
388071-5	Strut Assy Nose Landing Gear	1620-00-784-5556
388071-9	Strut Assy Nose Landing Gear	1620-00-784-5553
396175-11	Strut Assy Nose Landing Gear	
396175-13	Strut Assy Nose Landing Gear	
396175-17	Strut Assy Nose Landing Gear	
695001-9A	Strut Assy Main Landing Gear Shock	1620-00-111-1418
9235508-10	Strut Assy Nose Landing Gear	1620-01-399-1746

P/N	DESCRIPTION	NSN
65-22100-SERIES	Main Landing Gear	
65-22113-SERIES	Main Landing Gear	
65-65040-SERIES	Main Landing Gear	

P/N	DESCRIPTION	NSN
901918-5	Nose Landing Gear	1620-01-482-4581
901918-105	Nose Landing Gear	1620-01-103-2907

P/N	DESCRIPTION	NSN
200210078-10	Shock Strut Assembly	
200210078-20	Shock Strut Assembly	
200210078-30	Shock Strut Assembly	1620-01-515-8559
200210078-40	Shock Strut Assembly	1620-01-515-8560
200310056-10	Side Strut Assembly	1620-01-511-0037
200310056-20	Side Strut Assembly	1620-01-511-0039
200310057-10	Upper Side Strut Segment Assembly	1620-01-511-0042
200310057-20	Upper Side Strut Segment Assembly	1620-01-511-0041
200310059-10	Trunnion Assembly	1620-01-511-0043
200310059-20	Trunnion Assembly	1620-01-511-0045
458-56102-1	Trunnion Assembly	1620-01-143-1121
458-56102-2	Trunnion Assembly	1620-01-143-1122
458-56106-1	Drag Brace Assembly	1620-01-143-3293
458-56110-1	Truck Assembly	1620-01-143-0384
458-56123-1	Shock Strut Assembly	1620-01-143-1153
458-56123-2	Shock Strut Assembly	1620-01-143-1154
458-56124-1	Side Strut Assembly	1620-01-152-1372
458-56124-2	Side Strut Assembly	1620-01-148-0436
458-56125-1	Upper Side Strut Segment Assembly	1620-01-143-3294
458-56125-2	Upper Side Strut Segment Assembly	1620-01-143-3295
458-56130-1	Lower Side Strut Segment Assembly	1620-01-144-8474
458-56137-1	Upper Universal Assembly	1620-01-144-1398
458-56137-2	Upper Universal Assembly	1620-01-144-1399
458-56141-1	Lower Universal Assembly	1620-01-143-1152
458-56151-1	Torsion Link Assembly	1620-01-148-5695
7531273-100	Main Gear Oleo Assembly	1620-01-038-9101
7531273-110	Main Gear Oleo Assembly	1620-01-038-9102
7531273-120	Main Gear Oleo Assembly	1620-01-038-9101
7531273-130	Main Gear Oleo Assembly	1620-01-038-9102
7531273-140	Main Gear Oleo Assembly	1620-01-038-9101
7531273-90	Main Gear Oleo Assembly	1620-01-038-9102
8853035-10	Brake Collar Assembly	1620-01-153-2012
8853035-50	Brake Collar Assembly	1620-01-498-2055
9927108-10	Truck Assembly	1620-01-143-0384

P/N	DESCRIPTION	NSN
2006600-105	Nose Landing Gear Shock Strut Assembly	1620-01-072-8360
2006600-119	Nose Landing Gear Shock Strut Assembly	1620-01-098-2749
2006600-125	Nose Landing Gear Shock Strut Assembly	1620-01-124-9135
2006600-127	Nose Landing Gear Shock Strut Assembly	
2006600-129	Nose Landing Gear Shock Strut Assembly	1620-01-224-7090
2006600-131	Nose Landing Gear Shock Strut Assembly	1620-01-224-7091
2006600-135	Nose Landing Gear Shock Strut Assembly	
2006600-139	Nose Landing Gear Shock Strut Assembly	
2006600-143	Nose Landing Gear Shock Strut Assembly	1620-01-225-5457
2006600-147	Nose Landing Gear Shock Strut Assembly	1620-01-202-6349
2006600-151	Nose Landing Gear Shock Strut Assembly	
2006600-155	Nose Landing Gear Shock Strut Assembly	1620-01-162-7518
2006600-169	Nose Landing Gear Shock Strut Assembly	1620-01-474-1634
2006100-123	Main Landing Gear Shock Strut Assembly	1620-01-442-0946
965595-50	Main Landing Gear Shock Strut Assembly	1620-01-450-3214
2007100-103	Main Landing Gear Shock Strut Assembly	1620-01-252-1051
2007100-105	Main Landing Gear Shock Strut Assembly	