

Parker is the world's leading diversified manufacturer of motion and control technologies and associated systems.

AllClear partners with Parker to provide distribution of spare and R&OH support for KT-1, F-15, F-16 and UH-60 aircraft in various territories.



F-15 DAMPER SHIMMY



F-15 ENHANCED ENGINE
MONITOR DISPLAY



F-15 DIRECTIONAL
CONTROL VALVE, LINEAR



F-15 SAFETY RELIEF VALVE



F-15 FUEL SYSTEM VALVE



F-15 BUTTERFLY VALVE ASSEMBLY



F-15 MANIFOLD SUBASSEMBLY



F-16 REGULATING VALVE



F-16 TAIL FLAPERON
SERVO ACTUATOR




UH-60 HYDRAULIC POWER
SUPPLY PUMP



UH-60 WHEEL ASSEMBLY



UH-60 TAIL ROTOR
SERVO CYLINDER



UH-60 YAW ACTUATOR



UH-60 HYDRAULIC
POWER SUPPLY PUMP



C-130 AIR TURBINE STARTER
CONTROL VALVE

PART DESCRIPTION	NSN	PN	ALT P/N	PLATFORM	CAGE CODE
ACCUMULATOR	1650-00-502-3058	2710028	68-698015-103	F15	59211
RELIEF VALVE, SAFETY (for CFT) (2)	4820-01-018-4790	2740006	68-580109-105	F15	92003
FUEL FLOW TRANSMITTER	6620-01-310-0216	150-005-004	68-580066-107	F15	59211
FUEL FLOW INDICATOR	6620-00-468-9824	204-011-005	68-818011	F15	59211
FAN TURBINE INLET TEMPERATURE INDICATOR	6685-01-048-2889	208-004-010	68-810064-119	F15	26055
FLAP DRIVE ACTUATOR	1650-01-004-5794	2517000-1	68-690132-101	F15	93835
LINEAR DIRECTIONAL SELECTOR VALVE	4810-00-303-5851	2700234M1	68-690067-105	F15	92003
LINEAR DIRECTIONAL SELECTOR VALVE	4810-01-050-5228	2700249M6	68-690069-103	F15	93835
RELIEF VALVE, SAFETY (for CFT) (2)	4820-00-337-3985	2700271-1	68-580142-101	F15	92003
RELIEF VALVE, SAFETY (for CFT (2) and INTERNAL TANK)	4820-00-333-6666	2700271-2	68-580142-103	F15	92003
LINEAR DIRECTIONAL SELECTOR VALVE	4810-01-020-8093	2700313M5	68-690067-123	F15	92003
FLOAT VALVE (for CFT) (2)	2915-01-097-2423	2710853M4	68-580097-207	F15	82106
FLOAT VALVE, FUEL TANK	2915-01-097-0518	2710943M2	68-580097-203	F15	82106
POPPET VALVE	2915-01-065-3149	2710944M3	68-580097-211	F15	93835
CHECK VALVE	2915-01-169-9461	2710945-102	68-580115-103	F15	92003
FLOAT VALVE, PILOT	2915-01-116-0968	2750027-104	68-580097-209	F15	82106
LINEAR - DIRECTIONAL - SELECTOR VALVE	4810-01-050-5227	2760527-103	68-690067-125	F15	93835
SHUTOFF VALVE, FUEL	2915-01-140-5874	2780499-102	68-580097-213	F15	92003
PRESSURE CONTROL VALVE (for CFT) (2)	2915-01-094-3887	2790500-101	68-580097-215	F15	92003
FLUID PRESSURE REGULATING VALVE	4820-01-420-4761	2920001-101	68-580107-101	F15	82106
SERVOACTUATOR, DIFFUSER RAMP	1650-01-122-6948	3292000-11	68-690062-101	F15	93835
SERVOACTUATOR, STABILATOR (F-15E Model & subsequent)	1650-01-251-1153	3867000-2	68-690142-103	F15	93835
BUTTERFLY VALVE	4820-04-327-3582	5840203-101	68-830113-101	F15	92003
EMERGENCY POWER SUPPLY	6115-01-121-3632	63038-08	N/A	F15	93835
BRAKE ASSEMBLY	2815-01-580-8578	030-22501	N/A	KT1	33269
PARKING VALVE ASSEMBLY	1630-01-580-8809	060-00305	N/A	KT1	33269
PISTON, BRAKE, KT-1 AIRCRAFT	1630-01-581-2567	062-10101	N/A	KT1	33269
WHEEL ASSY, MAIN LANDING GEAR	1630-01-580-8770	040-42900	N/A	KT1	33269
TUBE FITTING, BRAKING SYSTEM	5325-37-Z06-5219	104-00300	N/A	KT1	33269
LINING MATERIAL, FRICTION	1630-01-392-9601	109-01500	768773050	KT1	33269
BRAKE PAD, WEAR	1620-01-580-8808	109-01501	N/A	KT1	33269
SPRING, HELICAL, COMP	5360-01-580-5005	082-09400	N/A	KT1	92003
DISC, ROTOR	1630-01-580-8663	159-06003	N/A	KT1	92003
CONE AND ROLLERS, TAPERED ROLLER BEARING	3110-01-448-6944	214-01300	N/A	KT1	33269
TORQUE LINER	1630-01-393-0118	205-03000	6068757287TBM	KT1	33269
VALVE, PNEUMATIC INFLATOR	4820-01-392-9606	160-01900	120573-11	KT1	33269
MAIN BRAKE ASSEMBLY	1630-01-089-2850	030-17700	70250-12060-102	UH60	92003
MAIN WHEEL ASSEMBLY	1630-01-331-2589	040-25300	70250-12801-101	UH60	59211
LOW LEVEL PILOT VALVE	4820-01-082-8343	1323-585285M1	70307-03025-101	UH60	3H889
MAIN BRAKE DISC	1630-01-114-9760	159-02000	N/A	UH60	33269
FUEL PUMP - AUXILIARY POWER UNIT	4320-01-369-9662	1B300-1	70307-03005-106	UH60	26433
SERVO ACTUATOR - TAIL ROTOR	1650-01-305-6954	2227000-17	70410-06520-046	UH60	93835
FUEL/DEFUEL VALVE	4820-01-095-7239	2750088-103	70307-03007-105	UH60	59211
SWING CHECK VALVE	4820-01-084-5493	2770006-101	70307-03045-101	UH60	92003
FUEL/DEFUEL CHECK VALVE	4820-01-237-3686	2770052-102	70307-03026-102	UH60	3H889
SWING CHECK VALVE	4820-01-096-1111	2770057-101	70307-03043-101	UH60	92003
HIGH LEVEL PILOT VALVE	4820-01-102-2465	2770076-102	70307-03012-103	UH60	92003
SELECTOR VALVE	1650-01-138-6674	2770546-102	7052-02290-102	UH60	92003
VALVE, CONE, CHECK	4820-01-288-5247	2780401-102	SS70-909P-6J	UH60	92003
RECEPTACLE, PRESSURE FUEL	2915-01-161-8377	2780482-101	70307-23905-101	UH60	3H889
HIGH LEVEL PILOT VALVE	2915-01-264-8603	2820049-101	65317-08218-101	UH60	59211
AIR TURBINE STARTER	2995-01-286-1498	36E144-12A	70306-10000-AV1	UH60	92003
AUXILIARY POWER UNIT CHECK VALVE (1.5 IN.)	4820-01-277-7846	5840227-101	70306-02116-101	UH60	3H889